

NOTES FOR INDIVIDUALS WITH LIMITED VISION

THE WINDOWS MAGNIFIER PROGRAM CAN BE USED IN CONJUNCTION WITH THE SPEECH RECOGNITION TUTORIAL TO MAGNIFY TEXT AND DISPLAYS IN THE TUTORIAL. THE MAGNIFICATION BOX SHOULD BE POSITIONED AT THE UPPER LEFT OF THE SCREEN FOR BEST RESULTS.

THE WINDOWS SOUND RECORDER PROGRAM OR SEPARATE RECORDING DEVICE CAN ALSO BE USED IN CONJUNCTION WITH THE SPEECH RECOGNITION TUTORIAL. FOR INDIVIDUALS WHO ARE UNABLE TO READ THE TUTORIAL EVEN WITH MAGNIFICATION, ANOTHER PERSON CAN READ AND RECORD THE TUTORIAL AND THE IMPAIRED PERSON CAN USE AN EARPHONE OR HEADSET AND A RECORDING-PLAYBACK DEVICE TO LISTEN TO THE RECORDING DURING THE SPEECH RECOGNITION TUTORIAL AND REPEAT THE NECESSARY WORDS INTO THE SPEECH RECOGNITION TUTORIAL MICROPHONE. THE RECORDING-PLAYBACK DEVICE WILL LIKELY NEED A REWIND AND REPLAY FEATURE THAT ALLOWS MULTIPLE PLAYBACK OF WORDS THAT NEED TO BE SPOKEN DURING THE TUTORIAL.